



www.perma-cool.com

Installation Instructions

This guide covers the following Item:

1135

*Congratulations, you have made a wise decision.
Thank you for purchasing our product.*

Oil Filter Adapter/Bypass Eliminator

IMPORTANT! READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION.

This filter adapter will convert your engine to a **FULL FLOW** system! For by-pass protection, one of the following filters MAY be used: Fram® PH4, Baldwin B279 or Purolator L35132.

With the engine cool to the touch, remove the oil filter. If applicable, remove the OE factory oil filter mount. Clean area of all debris, to ensure a clean mounting surface.

Coat the gasket with gasket cement. Place gasket in place between the engine and the adapter. Attach adapter to the engine using the new bolts provided. Install the adapter. Tighten bolts securely until snug, 18 ft. lbs. approximately.

Apply a thin film of fresh oil to the O-Ring on a new oil filter, and install onto the filter adapter. Tighten by hand 1/4 to 1/2 turn past O-Ring contact with sealing surface.

For additional accessories or replacement parts
visit www.perma-cool.com

© 2014 Perma-Cool

300044, rev. 3
Rev. Date: 11132013



www.perma-cool.com

Installation Instructions

This guide covers the following Item:

1135

*Congratulations, you have made a wise decision.
Thank you for purchasing our product.*

Oil Filter Adapter/Bypass Eliminator

IMPORTANT! READ ALL INSTRUCTIONS BEFORE BEGINNING

This filter adapter will convert your engine to a **FULL FLOW** system! For by-pass protection, one of the following filters MAY be used: Fram® PH4, Baldwin B279 or Purolator L35132.

With the engine cool to the touch, remove the oil filter. If applicable, remove the OE factory oil filter mount. Clean area of all debris, to ensure a clean mounting surface.

Coat the gasket with gasket cement. Place gasket in place between the engine and the adapter. Attach adapter to the engine using the new bolts provided. Install the adapter. Tighten bolts securely until snug, 18 ft. lbs. approximately.

Apply a thin film of fresh oil to the O-Ring on a new oil filter, and install onto the filter adapter. Tighten by hand 1/4 to 1/2 turn past O-Ring contact with sealing surface.

For additional accessories or replacement parts
visit www.perma-cool.com

© 2014 Perma-Cool

300044, rev. 3
Date: 11132013



www.perma-cool.com

Installation Instructions

This guide covers the following Item:

1135

*Congratulations, you have made a wise decision.
Thank you for purchasing our product.*

Oil Filter Adapter/Bypass Eliminator

IMPORTANT! READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION.

This filter adapter will convert your engine to a **FULL FLOW** system! For by-pass protection, one of the following filters MAY be used: Fram® PH4, Baldwin B279 or Purolator L35132.

With the engine cool to the touch, remove the oil filter. If applicable, remove the OE factory oil filter mount. Clean area of all debris, to ensure a clean mounting surface.

Coat the gasket with gasket cement. Place gasket in place between the engine and the adapter. Attach adapter to the engine using the new bolts provided. Install the adapter. Tighten bolts securely until snug, 18 ft. lbs. approximately.

Apply a thin film of fresh oil to the O-Ring on a new oil filter, and install onto the filter adapter. Tighten by hand 1/4 to 1/2 turn past O-Ring contact with sealing surface.

For additional accessories or replacement parts
visit www.perma-cool.com

© 2014 Perma-Cool

300044, rev. 3
Rev. Date: 11132013



www.perma-cool.com

Installation Instructions

This guide covers the following Item:

1135

*Congratulations, you have made a wise decision.
Thank you for purchasing our product.*

Oil Filter Adapter/Bypass Eliminator

IMPORTANT! READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION.

This filter adapter will convert your engine to a **FULL FLOW** system! For by-pass protection, one of the following filters MAY be used: Fram® PH4, Baldwin B279 or Purolator L35132.

With the engine cool to the touch, remove the oil filter. If applicable, remove the OE factory oil filter mount. Clean area of all debris, to ensure a clean mounting surface.

Coat the gasket with gasket cement. Place gasket in place between the engine and the adapter. Attach adapter to the engine using the new bolts provided. Install the adapter. Tighten bolts securely until snug, 18 ft. lbs. approximately.

Apply a thin film of fresh oil to the O-Ring on a new oil filter, and install onto the filter adapter. Tighten by hand 1/4 to 1/2 turn past O-Ring contact with sealing surface.

For additional accessories or replacement parts
visit www.perma-cool.com

© 2014 Perma-Cool

300044, rev. 3
Rev. Date: 11132013